



Care information

KADECO slats are resistant to dust and dirt because of the special coating that is applied to both sides. However, should you still wish to clean your blind, you will first need to remove the weighting plates and spacing chains from the drape. It is essential that you follow our specific care instructions by referring to the cleaning symbols.

Mechanical parts of electrical and winding units must not come into contact with water! Never use abrasive or alkaline detergents to clean glass or window frames. We cannot accept any liability for fabric damage caused by condensation, detergents or insects soiling the fabric. Nor can we accept any liability for any consequential damage due to incorrect handling of our products.



Brushing

Soiling (e.g. dust) can generally be removed with a soft clothes brush or carefully vacuumed off using a brush attachment.



Damp cloth

To wipe the individual slats with a damp cloth, place them on a smooth surface. Wipe the slats carefully on both sides with a soft cloth which has been moistened with mild detergent.



Hand wash

You can easily clean KADECO slats that are suitable for hand washing yourself. Please note that you must first remove the weighting plates and spacing chains from the vertical blind (if welded weighting plates are present, they can be left as they are). Clean the slats as follows:

- Remove the curtain of slats and gently roll 2 or 3 slats up together, without bending them.
- Place the rolls in a vessel containing a mild detergent solution (approximately 40 ml of detergent in 10 l of water) at a temperature of around 30° C for five to ten minutes. Then immerse them in clean water several times, or rinse them through, and leave to drip dry. Important: do not bend or wring the slats!
- Re-hang the slats whilst they are still wet and allow them to dry with the window open.



Machine wash

Please note that you must first remove the weighting plates and spacing chains from the vertical blind. If welded weighting plates are present, please follow the "Hand wash" instructions.

- Remove the slats and roll a maximum of 10 up together, without bending them.
- Carefully put the roll in a curtain washing bag and use mild detergent to wash one roll at a time, with the washing machine on a setting no hotter than 30° C. Important: do not use a spin cycle!
- Once they have been washed, hang the slats back into the rail whilst they are still wet. Place a towel underneath the slats to catch drips and allow them to dry with the window open.
- Attach the weighting plates and clip on the chain.

Ironing

We recommend that you iron only our uncoated fabrics, i.e. all Trevira CS qualities with the exception of the aluminised fabrics. Please use a steam iron at the lowest heat, with a cotton cloth between the slat and the iron, but only after consultation with us.